INSTALLATION PLAN

TYPE TF618 DISCHARGE HEAD

LAYNE & BOWLER INC. MEMPHIS, TENN.



USE THESE DIMENSIONS ONLY WHEN CERTIFIED BY FACTORY



HOLES IN BASE PLATE

BASE PLATE



HOLES IN BASE OF HEAD



SECTION THRU HEAD

CUSTOMER: City of
LOCATION: Georgetown, [redacted] S.C.
FOR APPROVAL:
CERTIFIED: John Fenwick

YOUR NO. S-150-66
OUR NO. 66D-4114
PUMP NO. 55032
DATE: June 18, 1966

GPM 300
TDH 475
R.P.M. 1750
B.H.P.

HEAD	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S
TF413	13	6	11	18	9	8-3/4	7 1/2	14 1/8	11/16	2 13/16	10	16 15/16	7/8	21	2	17
TF613	14	6	11	18	11	8-7/8	9 1/2	14 1/8	11/16	2 7/8	11	16 15/16	7/8	21	2	17
TF418	13	6	14 1/4	23	9	8-3/4	7 1/2	17 5/16	13/16	2 13/16	10	20 1/16	7/8	26 1/2	2 3/4	21 3/4
TF618	15	6	14 1/4	23	11	8-7/8	9 1/2	17 5/16	13/16	2 7/8	12 1/2	20 1/16	7/8	26 1/2	2 3/4	21 3/4
TF818	18	7 3/32	14 1/4	23	13 1/2	8-7/8	11 3/4	17 5/16	13/16	3 1/16	13 1/2	20 1/16	7/8	26 1/2	2 3/4	21 3/4
TF1018	18	8 1/8	14 1/4	23	16	12-1	14 1/4	17 5/16	13/16	3 11/16	16	20 1/16	7/8	26 1/2	2 3/4	21 3/4
TF1218	20	9 5/8	16 1/4	26	19	12-1	17	19 5/8	13/16	3 11/16	19	23 11/16	7/8	32	3 1/4	24

HEAD	A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S
TF625	15	8 1/8	18 1/4	31	11	8-7/8	9 1/2	23 11/16	13/16	2 7/8	12 1/2	29	1	38	3 3/4	29
TF825	20	8 1/8	18 1/4	31	13 1/2	8-7/8	11 3/4	23 11/16	13/16	3 1/16	13 1/2	29	1	38	3 3/4	29
TF1025	20	8 1/8	18 1/4	31	16	12-1	14 1/4	23 11/16	13/16	3 11/16	16	29	1	38	3 3/4	29
TF1225	21	9 5/8	18 1/4	31	19	12-1	17	23 11/16	13/16	3 11/16	19	29	1	38	3 3/4	29
TF1225I	21	9 5/8	18 1/4	31	19	12-1	17	23 11/16	13/16	4 7/16	21	29	1	38	3 3/4	29
TF1425	21	10 5/8	18 1/4	31	21	12-1 1/8	18 3/4	23 11/16	13/16	4 7/16	21	29	1	38	3 3/4	29
TF1227	24 1/2	9 3/4	21	36	19	12-1	17	27 5/8	13/16	3 11/16	19	33 3/8	1	43	4 1/4	33 7/8