



tie in 4" Hdpe into new 12" DIP, install inline valve on 12" each side of creek

Tie new 2" HDPE line into new 12" Dip

12" HDPE Sewer force main

6" DIP Stub Out w/ FH

New 12" DIP main & direct tap

tie new 8" DIP main inside 16" HDPE Casing into 12" DIP

install 12" DIP from valve cluster back to new 14" HDPE. Install 8" FH w/ 8" inline valve on 12" main

Existing water main

Tie new 12" DIP into existing 8" DIP