


BINDING EDGE


BINDING EDGE

BINDING EDGE




NOTE
1. BACKFILL ON SERVICE LINES TO BE STONE BACKFILL AS SHOWN.

SANITARY SEWER SERVICE LINE
NOT TO SCALE



SHARED SANITARY SERVICE CONNECTION DETAIL
NOT TO SCALE




SECTION (SERVICE LINE CLEANOUT ON PRIVATE PROPERTY)

NOTES:
1. ALL FITTINGS AND LINES TO BE SDR 35 PVC (SOLVENT WELD).
2. WHEN SERVICE LINE FROM MAINLINE IS 4", ALL FITTINGS AND LINES TO BE 4".
3. TOP OF CLEANOUT SHALL BE FLUSH WITH GRADE UNLESS DIRECTED OTHERWISE BY OWNER.


SANITARY SEWER CLEANOUT
NOT TO SCALE

NOTE
1. EXISTING CONCRETE SIDEWALK WILL BE SAW CUT AND REPLACED WITH A FULL-DEPTH SIDEWALK SECTION.




TYPICAL CONCRETE SIDEWALK
NOT TO SCALE

NOTE
1. EXISTING ASPHALT WILL BE SAW CUT AND REPLACED WITH A FULL-DEPTH ASPHALT PAVEMENT SECTION. A TWO YEAR PERFORMANCE BOND AND A THREE YEAR MAINTENANCE BOND WILL BE REQUIRED FOR ASPHALT PAVEMENT SECTION TRENCH REPAIR AREAS.



ASPHALT PAVEMENT SECTION TRENCH REPAIR
NOT TO SCALE



P.V.C. SANITARY SEWER BEDDING DETAIL
NOT TO SCALE

TEMPORARY SEEDING MIXTURES

SEEDING DATES	GRASS SEED	PERCENTAGES
JANUARY 1 TO MAY 1	ITALIAN RYE	50%
	SUMMER OATS	50%
MAY 1 TO JULY 15	SUDAN-SORGHUM	100%
MAY 1 TO JULY 15	STARR MILLET	100%
JULY 15 TO JANUARY 1	BALDOA RYE	67%
	ITALIAN RYE	33%


SOURCE: TDOT STANDARDS SPECIFICATIONS

PERMANENT SEEDING MIXTURES


SEEDING DATES	GRASS SEED	PERCENTAGES
FEBRUARY 1 TO JULY 1	KENTUCKY 31 FESCUE	88%
	ENGLISH RYE	12%
JUNE 1 TO AUGUST 15	KENTUCKY 31 FESCUE	60%
	GERMAN MILLET	15%
	ENGLISH RYE	25%
AUGUST 1 TO DECEMBER 1	KENTUCKY 31 FESCUE	70%
	ENGLISH RYE	20%
	WHITE CLOVER	10%
DECEMBER 1 TO FEBRUARY 1	KENTUCKY 31 FESCUE	83%
	ENGLISH RYE	17%

SOURCE: TDOT STANDARDS SPECIFICATIONS


SEEDING SCHEDULE
NOT TO SCALE



SILT BAG INLET PROTECTION DETAIL
NOT TO SCALE




SECTION
NOT TO SCALE



PLAN
NOT TO SCALE

FILTER SOCK
NOT TO SCALE



SLOPE EROSION CONTROL BLANKET / MATTING
NOT TO SCALE.

- NOTES:**
- PREPARE SOIL BEFORE INSTALLING BLANKETS, INCLUDING APPLICATION OF LIME, FERTILIZER, AND SEED.
 - GRADE THE SURFACE BEFORE INSTALLATION SO THE GROUND IS SMOOTH AND SOIL LOOSE. ALL GULLIES, RILLS, AND OTHER DISTURBED AREAS MUST BE FINE GRADED PRIOR TO INSTALLATION.
 - SPREAD SEED BEFORE BLANKET INSTALLATION.
 - REMOVE ALL LARGE ROCKS, DIRT CLOUDS, STUMPS, ROOTS, GRASS CLUMPS, TRASH, AND OTHER OBSTRUCTIONS FROM THE SOIL SURFACE TO ALLOW DIRECT CONTACT BETWEEN THE SOIL AND BLANKET.
 - PLACE BLANKET 2-3 FEET OVER THE TOP OF THE SLOPE AND INTO AN EXCAVATED END TRENCH 12" DEEP* WIDE BACKFILL AND COMPACT THE TRENCH AFTER STAPLING.
 - ROLL THE BLANKETS (A) DOWN OR (B) HORIZONTALLY ACROSS THE SLOPE.
 - OVERLAP ADJACENT ROLLS A MINIMUM OF 3 INCHES.
 - PIN THE BLANKET TO THE GROUND USING STAPLES OR PINS IN A 3' CENTER-TO-CENTER PATTERN, OR AS RECOMMENDED BY THE MANUFACTURER.
 - WHEN BLANKETS MUST BE SPLICED DOWN THE SLOPE, PLACE BLANKETS END OVER END (SHINGLE STYLE) WITH APPROXIMATELY 12" OVERLAP. STAPLE THROUGH OVERLAPPED AREA, APPROXIMATELY 12" APART.
 - EROSION CONTROL BLANKETS SHALL BE INSTALLED ON ALL 5:1 SLOPES WITH A MINIMUM OF 6 INCHES OF TOPSOIL.
 - FOR ALL SLOPES 3:1 OR STEEPER, TEMPORARY EROSION CONTROL BLANKET (TENSAR NORTH AMERICAN GREEN S150 OR APPROVED EQUAL) SHALL BE USED IN PLACE OF STRAW MULCH.
 - FOR PERMANENT STABILIZATION OF DRAINAGE DITCHES, INSTALL TURF REINFORCEMENT MATTING (TENSAR NORTH AMERICAN GREEN S250 OR APPROVED EQUAL) INSTALLED PER MANUFACTURER'S RECOMMENDATIONS.
 - REFER TO MANUFACTURER'S INSTRUCTIONS FOR SPECIFIC INSTALLATION PROCEDURES.

